

Jet Trax
Watercraft and Motorcycle Mounting Plate
Installation Instructions



Jet Trax of California
PO Box 2664
Santa Clarita, CA 91386-2664
1-800-953-8729

Jet Trax Installation Instructions

These instructions are to insure proper installation, which will enhance the safety and reliability of your Jet Trax System. The Jet Trax System is designed to provide years of dependable service without undue maintenance cost or operations problems. By following these step-by-step instructions, your Jet Trax System will become a secure and reliable transporting and loading device.

STEP 1

Read these instructions completely before starting the installation. Pay particular attention to all of the safety notes.

STEP 2

Installation of the Universal Mounting Plate

This mounting plate can be used on all Jet Trax systems. The basic installation consists of:

- ✓ Bolting down the furnished mounting plate
- ✓ Bolting the Jet Trax System to the plate.
- ✓ Bolting down the rear of the Jet Trax system

You will find a ½" X 3" X 48" flat bar packed with your system. This bar has smooth holes drilled through it and also has threaded holes to accept the 2 ¼ " long bolts found in the hardware bag located in the battery box.

- A. Slide the Jet Trax unit into the truck bed, and close the tail gate, making sure that the Jet Trax unit has approximately ½" clearance in the back with the tail gate closed. Scribe a mark along the front of the 3" channel at the front of the truck bed. This will show you where the universal mounting plate is to be mounted. Center the universal mounting plate in the truck bed along the scribe line.
 - a. On a FORD, use the holes outside of the tapped holes. Drill two 9/16" holes through the bed and secure with 2 ½" bolts and nuts provided. A 3" square plate is provided to be used as a large washer and add structural support under the bed of the truck.
 - b. On a DODGE, CHEVROLET, or GMC truck, two holes must be drilled. Choose two holes in the plate that are between the tapped holes. Mark the hole location and drill a 9/16" hole through the bed and bed cross members and secure with the 5 ½" bolts and nuts provided.

- B. Once the mounting plate is installed, slide the Jet Trax unit into the truck bed, until the 3” channel iron on the front of the Jet Trax straddles the mounting plate. Put the 2 ¼” bolts into the lock washers and flat washers, then through the oval holes in the Jet Trax base. The bolts will go into the threaded holes in the mounting plate. Tighten securely. Check all mounting hardware periodically.

STEP 3

Drilling the back hole

- A. Center the Jet Trax unit in the truck bed. Through the existing hole in the back of the Jet Trax unit, mark and drill a 9/16” hole through the bed of the truck. Put the 3 ½” bolt into the lock washers and flat washers, then through the Jet Trax unit. Tighten the bolt securely under the truck.

If you encounter any difficulties in the installation process, representatives are available 8:00 AM to 5:00 PM, Pacific Standard Time, to answer any questions. Call toll free (800) 953-8729.

Steps to insure safe and proper operation of your Jet Trax System

System Checkout

- 1) Check to make sure that your Jet Trax unit is securely fastened onto you vehicle with the mounting plate, bolts and hardware.
- 2) Check the battery to see that it is fully charged and ready for use.
- 3) Check the safety transport pin, at the rear of the transport unit. The transport safety pin should be in place at all times. The only exception would be loading and unloading.
- 4) Check to make sure that your watercraft is secured using a nylon strap from the back of the watercraft down to the bumper of the truck.

NEVER ALLOW anyone in the back of the vehicle while the loading or unloading operation is in progress. **PERSONAL INJURY MAY RESULT!!**

Following these directions, steps and warnings will help insure safety and enjoyment while using your personal watercraft or motorcycle and the Jet Trax Transport System.

If you have any questions, please give us a call at 1-800-953-8729.

WE HOPE YOU ENJOY USING YOUR JET TRAX SYSTEM!